

MCD50 SPARE PARTS LIST				
No.	Description			
1	Handle cover			
2	Feed handle			
3	Hub			
4	O ring			
5	Scale ring			
6	Bushing			
7	Spring pin			
8	Gear shaft			
9	Hex nut			
10	Set screw			
11	Hose holder			
12	Hose			
13	Flat washer			
14	Pan head screw			
15	Hose clamp			
16	Socket head screw			
17	Body			
18	Strain relief			
19	Hex nut			
20	Pan head screw			
21	Serrated washer			
22	Flat washer			
23	Retaining ring			
24	Shaft support			
25	Socket head screw			
26	Strain relief			
27	Protection bar			
28	Strain relief			
29	Strain relief			
30	Switch box			
31	Thread forming screw			
32	Thread forming screw			
33	Rectifier			
34	Power cord			
35	Control panel			
36	Indicator light			
37	Circuit breaker			
38	Switch for motor			
39	Switch for electromagnet			
40	Thread forming screw			
41	Flat washer			
42	Terminal			
43	Thread forming screw			
44	Electromagnet			
45	Hex nut			
46	Socket head screw			
47	Rack			
48	Socket head screw			
49	Socket head screw			
50	Socket head screw			
51	Socket head screw			
52	Motor rear cover			
53	Guide			
54	Socket head screw			
55	Sliding block			
56	Socket head screw			
57	Flat head screw			
58	Cord clamp			
59	Motor housing			
60	Pan head screw			

MCD50 SPARE PARTS LIST				
No.	Description			
61	Brush cover			
62	Spring of brush			
63	Brush			
64	Brush holder			
65	Insulation cover			
66	Stator			
67	Socket head screw			
68	Ball bearing 629zz			
69	Rotor			
70	Ball bearing 6001zz			
71	Wind shield			
72	Motor front cover			
73	Set screw			
74	Ball bearing 629zz			
75	Washer			
76	48 teeth gear			
77	Key			
78	Combination gear			
79	Ball bearing 629zz			
80	Socket head screw			
81	Flat washer			
82	54 teeth gear			
83	Bushing			
84	Clutch			
85	Retaining ring			
86	Washer			
87	58 teeth gear			
88	Bushing			
89	Ball bearing 6005zz			
90	Socket head screw			
91	Pushing plate			
92	Sliding bracket			
93	Guide			
94	Eccentric shaft			
95	Support block			
96	Socket head screw			
97	Steel ball			
98	Spring			
99	Knob			
100	Pan head screw			
101	Pan head screw			
102	Lock washer			
103	Gear box			
104	Socket head screw			
105	Limited bar			
106	Thrust ball bearing			
107	Washer			
108	Ball bearing 6006ZZ			
109	Spindle			
110	Retaining ring			
111	Bushing			
112	Oil seal			
113	Coolant house			
114	Limited bar			
115	Tool holder			
116	Set screw			
117	Spring			
118	Sliding block			
119	Limited collar			
120	Retaining ring			

